




Spare Parts List

FLS4.2 TRANSMISSION

ref 398082



Pos.	Ref.	Q.ty	Descrizione	Description	Kit	Note
1	398082	1	Trasmissione Fls4.2	Transmission Fls4.2 Assy		
2	834677	1	Flangia	Flange		
3	834103	1	Anello	Ring		
4	837725	1	Corona Z44	Crown Gear		
5	334075	1	Manicotto	Sleeve		
6	334042	1	Ingranaggio	Gear		
7	834847	1	Spingidisco	Pressure Plate		
8	834851	1	Rondella	Pressure Ring		
9	020052	1	Anello Elastico	Circlip		
10	023142	1	Anello Elastico	Circlip		
11	020611	4	Vite	Cylinder Head Screw		
12	834775	4	Rondella	Disk/washer		
13	833470	1	Rondella	Disk/washer		
14	867717	-	Rondella	Disk/washer		
15	834439	-	Rondella	Disk/washer		
16	834438	-	Rondella	Disk/washer		
17	025970	1	Cuscinetto	Ball Bearing		
18	022792	1	Cuscinetto	Ball Bearing		
19	020961	-	Spessore	Shim Ring		
20	020963	-	Spessore	Shim Ring		
21	020039	1	Seeger	Snap Ring		
22	021830	2	Spessore	Shim Ring		
23	021892	1	Spessore	Shim Ring		
24	831517	1	O-ring	O-ring		
25	020694	-	Spessore	Shim Ring		
26	831463	1	O-ring	O-ring		
27	137474	1	Sfiato	Breather		
28	021971	8	Vite	Cylinder Head Screw		
29	831462	1	O-ring	O-ring		
30	831459	1	O-ring	O-ring		
31	831870	2	Tappo	Screw Plug		
32	022095	1	Tappo	Screw Plug		
33	855205	1	Flangia	Flange		

